



Note:

1. This detail is not appropriate for APP modified bitumen membranes.
2. See flashing specs in Appendix I.
3. After the base flashing has been installed, nail top edge 9" o.c. through tin discs. Install two courses of ply felts 4" & 6" wide, respectively, in 1/8" thick FlintBond Trowel to the primed wall & between courses. Finish with 1/8" thick trowel coat.

**Concrete or Masonry Wall Base Flashing with a
5-Course Flashing System
(Not Suitable for Stucco Wall Assemblies)**

CertainTeed
SAINT-GOBAIN
Commercial Roofing

ISSUE DATE 8/30/2013	REVISION B	DRAWING NUMBER CT-07
SCALE Not To Scale		Sheet 1 of 1